



正確使用 + 定期檢修 → 安全用電
Proper Use + Regular Maintenance → Electrical Safety


電力法例  機電工程署

香港九龍啟成街 3 號
Electricity Legislation
Electrical and Mechanical Services Department
3 Kai Shing Street, Kowloon, Hong Kong
電話 Tel.: (852) 1823 傳真 Fax: (852) 2895 4929
網址 Homepage: www.emsd.gov.hk
電郵 E-mail: info@emsd.gov.hk

電暖爐


安全須知

Safety Tips for **Electric Heaters**



★ 切勿購買或使用兩腳插頭的電暖爐。

Do not purchase or use an electric heater fitted with a 2-pin plug.



★ 切勿在浴室內使用電暖爐。

Do not use electric heater inside a bathroom.



★ 切勿將可燃物料（例如雜誌、衣物等）放近使用中的電暖爐。

Do not put any combustible materials such as magazines, clothes, etc. near an operating electric heater.



★ 勿讓小孩接近電暖爐。

Keep children away from an electric heater.




★ 若電暖爐有異常情況，例如過熱或漏油等，必須停止使用及安排有經驗的技師檢查。

Stop using an electric heater if there is any abnormal condition such as overheating, oil leakage, etc. and arrange for inspection by an experienced technician.




★ 清潔電暖爐前，必須關掉電源和拔出插頭。

Switch off and unplug before cleaning.



★ 遵照說明書指示使用及保養電暖爐。

Adhere to the user manual for use and maintenance.



★ 使用前，必須檢查有否損壞。

Check for damage before use.

